


Fig. 1

- Signaling interface
- Signaling and data transfer interface

: }



Uplink Radio Connection Establishment Req
Uplink Radio Connection Established Cnf
Data "Request"
Uplink Radio Connection Released
Uplink Radio Connection Released Cnf

"Request"

"Answer"

Downlink Radio Connection Establishment

Downlink Radio Connection Released

"Data Answer"

Downlink Radio Connection Released


Downlink Radio Connection Released


Downlink Radio Connection Released

Downlink Radio Connection Released

Fig. 3

fig. 4





b

, e .

